

THIS PAGE SHOULD NOT BE PRINTED

Paper Secification :  
80-90 GSM Coated paper

Colour used in the artwork :  
Pantone 2728C 

Typface used :  
Jiotype Medium, Jiotype Light

Open Size : 315\*148 mm  
Folded size : 105\*148 mm

Type of printing : Double sided


# Welcome to the Digital World of Jio.



You are the proud owner of  
**Jio Game Controller**  
JGC100

## 1 Introduction

Jio Game Controller



### Compatible Devices with this Gamepad



Android TV box / Android phone, tablet

## 2 Technical Specifications

Gamepad	Jio GameController
Connectivity	Bluetooth 4.1
Frequency band	2400 ~ 2483MHz
Output Power	Class 2
Transmission Range	7~10 M
Supported profiles	HID
Playing time	8h
Charging time	1h
Size	153(W) x 110 (L) x 59 (H) mm
Weight	200g including battery

## 3 Overview of LED signals

NOTE: LED Signals refer to the 4 blinking lights above the power button, as you can find in the diagram on the left.



- Mode Change: Set up mode corresponding to your device by booting with combination [Jio+LB] button. Please power off [press Jio more than 3 sec] before booting.
- Pairing: Press the [Select+Start] button for 3 seconds at the same time

## 4 Pairing the controller

### STEP 1: Turn power ON

- When the gamepad is turned on by pressing the Jio button, default is in Android mode. To pair with an Android device, please follow step 2 based on the device you wish to connect with the gamepad.
- After initial set up is complete, the gamepad will remember your device to connect automatically.

### STEP 2: Connecting with an Android Device (Phone, Tablet and TV)

- 1 Mode Set Up: When the power is off, press [ Jio + LB] buttons simultaneously for booting.
- 2 Select Mode: Check if LED signals #1 and #2 are off, #3 and #4 are on, If yes, It is connecting to an Android device, If not, please repeat step above.
- 3 Bluetooth Pairing: Press [Select+Start] simultaneously for seconds, On your device, select "Jio JGC100 XXXX". Once paired, gamepad will remember and will reconnect automatically.

## 5 Charge and reset

### How to charge

Change battery with charging cable to a computer or USB power charging device (5W)

#### When battery is low

Jio Fast blinking

#### When it is charging

Jio Slow blinking


#### When it is charged fully

Jio Stops blinking

**NOTE: DO NOT PLAY WHILE THE DEVICE IS CONNECTED OR IN CHARGING MODE.**

### How to reset

Press reset button located on back of the device just once with a proper pin.



With love, from Jio.



We continuously update our product, scan the above QR Code using your smartphone to see the latest information about the product.

Copyright ©2021, Reliance Retail Limited.

All rights reserved. No part of this publication may be reproduced, excerpted, translated or utilized in any form or by any means either electronically or mechanically, including photocopying and microfilm without the prior permission of Reliance Retail Limited. This manual is published by Reliance Retail Limited and it reserves the right to make modifications on print or update specifications without prior notice.

#### Reach us at

Visit us  
Email us  
Toll Free Number

www.jio.com  
jiofibercare@jio.com  
1800 89 69999